

## Addendum to User's Manual 250-0225

Due to an error which was not caught until after the print run was completed, Figure 8 in the manual is illegible. The correct illustration is shown below.

For additional assistance, contact your local Minarik® distributor, or the factory direct by telephone at:

1-800-MINARIK (646-2745) or Fax: 1-800-394-6334




Figure 8. DISABLE/ENABLE Terminals

©1999 Minarik Automation and Control.

All rights reserved. Printed in the USA 8/99

Document no. 250-0225a