



Bravo®
Accessory Kits

ITEM #	DESCRIPTION						
1	GEAR MODULE	11	SOCKET HEAD CAPSCREW	20,20P,20X	INPUT SHAFT - NON-MOTORIZED INPUT	29	CONNECTOR FLANGE - DOUBLE REDUCTION
2,2P	OIL SEAL - OUTPUT	12	REACTION ARM	21,21P,21X	KEY - INPUT (EXTENSION)	30	O-RING
3	RCA SEAL PLUG	13	RETAINING RING	22,22P,22X	KEY - INPUT (INTERNAL)	31	SOCKET HEAD CAPSCREW
4,4P	DRAIN PLUG	14	SPACER	23,23P,23X	GASKET	32,32P,32X	SOCKET HEAD CAPSCREW
5	FL-SPACER	15	OUTPUT SHAFT - DOUBLE EXTENSION	24	CONNECTOR SHAFT	33,33P,33X	HEX HEAD CAPSCREW
6	F-FLANGE	16	OUTPUT SHAFT - SINGLE EXTENSION	25	KEY	34	PRIMARY GEAR MODULE - DOUBLE REDUCTION
7	SOCKET HEAD CAPSCREW	17	KEY-OUTPUT (EXTENSION)	26	KEY	35	HELICAL STEP MODULE - DOUBLE REDUCTION
8	SOCKET HEAD CAPSCREW	18	KEY-OUTPUT (INTERNAL)	27,27P,27X	FLANGE - MOTORIZED INPUT	36	SOCKET HEAD CAPSCREW
9,9P,9X	OIL SEAL - NON-MOTORIZED INPUT	19,19P,19X	OIL SEAL - MOTORIZED INPUT	28	INPUT COVER	37	NAMEPLATE
10	HORIZONTAL BASE					38	GASKET