






























# MM23001A-SPEC.0475 CALIBRATION GUIDE

## 90 VDC MOTORS



 TORQUE	 IR COMP	1 HP 1750 RPM 10 AMP RATING	 TORQUE	 IR COMP	1/4 HP 1750 RPM 2.7 AMP RATING
 TORQUE	 IR COMP	3/4 HP 1750 RPM 7.6 AMP RATING	USING 0.05 OHM FEEDBACK RESISTOR		
 TORQUE	 IR COMP	1/2 HP 1750 RPM 5 AMP RATING	 TORQUE	 IR COMP	1/8 HP, 130 VDC 2500 RPM 1 AMP RATING
 TORQUE	 IR COMP	1/3 HP 1750 RPM 3.5 AMP RATING	 TORQUE	 IR COMP	1/12 HP, 130 VDC 2500 RPM 0.71 AMP RATING

## 180 VDC MOTORS

 TORQUE	 IR COMP	2 HP 1750 RPM 9.2 AMP RATING	 TORQUE	 IR COMP	1/2 HP 1750 RPM 2.5 AMP RATING
 TORQUE	 IR COMP	1 1/2 HP 1750 RPM 7 AMP RATING	USING 0.05 OHM FEEDBACK RESISTOR		
 TORQUE	 IR COMP	1 HP 1750 RPM 5 AMP RATING	 TORQUE	 IR COMP	1/4 HP 1800 RPM 1.3 AMP RATING
 TORQUE	 IR COMP	3/4 HP 1750 RPM 3.8 AMP RATING	 TORQUE	 IR COMP	1/8 HP 1800 RPM 0.67 AMP RATING

**NOTE:**  
IR COMP & TORQUE trimmer pots must be re-calibrated using the following calibration guide after the resistor is clipped.



901 East Thompson Avenue  
Glendale, California 91201-2011  
Phone: (800) MINARIK or (800) 646-2745  
Fax: (800) 394-6334  
www.minarikcorp.com  
Document number 250-0166, Rev 2  
Printed in the U.S.A - 4/01